



Tools Needed for Assembly

- 1/4" socket drive handle
- 1/4" ratchet wrench
- 1/4" flex extension 8 to 10 inches long
- Deep Well Sockets
 - a) 7/16"
 - b) 3/8"
 - c) 11/32"
 - d) 1/4"
- T15 Tamper-Resistant Torx driver (Torx TR)
- T25 Tamper-Resistant Torx driver (Torx TR)
- #1 Phillips screwdriver
- #2 Phillips screwdriver
- Wire cutters
- 3/4" open end wrench
- 5/8" open end wrench
- #2 Robertson square drive